

FLOOR GRAPHIC

FOR NON-CARPETED FLOORS

Tips for Best Results

- Designed for smooth floor surfaces such as hardwood floors, tile, and sealed concrete.
 - Be mindful of temperature and install only when temperatures are above 50°F (10°C). Avoid applying over corrugated surfaces and across any gaps.
 - **FLOOR PREP & MAINTENANCE:** The floor surface must be clean prior to applying the graphics. Clean the floor surface as you would normally. Be sure to allow enough time for the surface to completely dry before applying the graphic. Do not clean or wax graphics for at least 24 hours after application. (When selecting a floor wax, ensure it meets or exceeds ASTM D 2047 standards.)
-

Instructions

- 1** The next step is applying the floor graphic to the floor surface. We recommend laying out the floor graphics ahead of time to ensure proper placement and positioning.
 - 2** Begin by peeling off the backing paper (release liner) 1-2 inches down from the top of the decal. Fold and crease the backing paper.
 - 3** Align and apply the graphic starting at the top. The adhesive backing is quite strong so make sure the graphic is in position before applying. Once the graphic is in place, use firm strokes with a plastic squeegee or a soft cloth until the entire adhesive makes contact with the floor surface.
 - 4** Slowly peel down the backing paper a few inches at a time while continuing to smooth out any air pockets or wrinkles with the squeegee. When finished, re-squeegee around the edges of the graphic to make sure all edges are adhering properly to the floor surface.
- **CAUTION:** To avoid risk of injury, remove any graphic where the edges lift off the floor surface and create a tripping hazard.
-

Removal Instructions

Lift up one edge of the graphic and pull using short quick strokes. For best results, pull up an angle less than 45 degrees.